

### **PACKING LIST**

- 1 x Start
- 1 x handset
- 1 x handset cord
- 1 x stand
- 1 x Ethernet cable

### SAFETY INFORMATION

https://www.wildix.com/safety-information/

## **MOUNTING INSTRUCTIONS**

Attach the stand to the phone (desk mounting) or hang the phone on the wall (without attaching the stand).

### CONNECTION

The ports are situated on the rear panel of the phone

- Connect the handset to the port using the handset cord
- Connect the phone to the network PoE switch using RJ-45 cable
- (Optional) Connect the port to the PC using RJ-45 cable
- (Optional, this is a PoE device) Connect the phone to the power supply (power adapter can be purchased separately, WMP code: PS-5V2A)
- (Optional) Connect the headset to the port (headsets can be purchased separately)

### LOGIN

- 1. Lift the receiver and dial 99
- 2. Enter your extension number
- 3. Enter the first five characters of your password
- 4. Press 1 when prompted

To enter your password from the phone's keypad: press once an alphanumeric key corresponding to a letter which you need to enter; press the star button (\*) to enter any special character.

Example: Password: 4Ag7\$ZI@

Enter: 4247\*



#### **BLF / FUNCTION KEYS**

Function keys must be set up in Collaboration Settings -> Fn keys / x-bees -> Favorites, or by the PBX administrator.

This phone supports up to 4 Function keys distributed over 2 pages. Use **Navigation keys** to move between pages.

### **CALL FEATURES**

Press **Feature** Soft key from the standby mode to set the following call features for each call type (Internal, External, Blacklist, Whitelist), based on user status (Available, DND, Away): Call reject, Call forwarding, Call Waiting, Mobility, Ring Tone.

Features can be also set up in Collaboration / x-bees / WMS / iOS/Android / x-bees app.

### **PHONE OVERVIEW**



DCSV

Version 03/2024 Page 1 of 2



# **PLACE A CALL**

<u>Manually</u>: Lift the handset, enter the number and press **Send** Soft key.

To switch between speaker mode and handset mode during a call: press **Speaker** key. To switch between speaker mode and headset mode during a call: press **Headset** key.

Dial a user for whom you have assigned a *Colleague* Function key: press the corresponding **Function key**.

<u>Call from call history:</u> press **History** Soft key from idle and select the number using **Navigation keys**, then press **Dial** Soft key.

## Call from Phonebooks:

- 1. Press Phonebook key
- 2. Press Filter Soft key and select a phonebook
- 3. Press **Search** Soft key to search the phonebook and enter the name or phone number
- Press Enter Soft key and select the contact using Navigation keys
- 5. Press Dial Soft key

Phonebooks must be set up by user via Collaboration or by the PBX administrator.

## **MUTE, SPEAKER, VOLUME CONTROL**

Press **Mute** key to mute / unmute the microphone.

Press Volume Up / Down keys to adjust the volume.

Press Speaker key to turn on the Speaker mode.

### **HOLD / SECOND CALL**

- 1. Press Hold Soft key during a call to put a call on hold
- Press More Soft key -> New Soft key to make a second call, then enter the number manually or press Select Soft key to search for the contact in call history / in phonebooks

## **CONFERENCE**

- 1. Press More Soft key
- 2. Press Conf Soft key during a call (active call is put on hold)
- 3. Make a second call to the contact you would like to invite to the conference call
- 4. When the third party answers, press Conf Soft key

### **ACCESS VOICEMAIL**

- 1. Press Voicemail key
- 2. If requested, enter the first five characters of your password
- Select the message and press Play Soft key to listen to it; press Info Soft key for more information or to delete the message

Full guide online:



www.wildix.com

### **CALL TRANSFER**

<u>Blind transfer</u> (the desired party/extension is not notified of the impending transfer)

- Press Transfer key during a call (the call is put on hold)
- 2. Dial the desired party/extension
- 3. Hang up

Blind transfer via Colleague BLF / Function key: make sure Direct transfer option is enabled for this Function key in Collaboration / x-bees:



1. Press the corresponding Function key during a call

Attended transfer (the desired party/extension is notified)

- Press Transfer key during a call (the call is put on hold)
- 2. Dial the desired party/extension
- 3. Notify the third party of the impending transfer
- 4. Hang up to transfer the call

Attended transfer via Colleague BLF / Function key: make sure Direct transfer option is disabled for this Function key in Collaboration / x-bees:



- Press the corresponding Function key during a call (the current call is put on hold)
- 2. Notify the third party of the impending transfer
- 3. Hang up to transfer the call

## STATUSES AND NOTIFICATION ICONS OVERVIEW

	IP obtaining is in progress
<b>X</b> loginX	Under provisioning
✓ loginX	Provisioned and ready to be assigned
<b>✓</b>	Online
	Away
	DND
	Incoming call
	Call in progress
V	Missed call
	Outgoing call
	Call on hold
<b>½</b>	Muted microphone
<b>III</b> )	Speaker activated
HD	Call is established via Opus codec
A	Call is established via SRTP
	Voicemail
III ×	Silent mode activated
CFN:X	CFN:destination number/ voicemail -> Call Forwarding activated

Version 03/2024 Page 2 of 2